
Operation 6005

ritëtemp.



This unit is a "heating only" unit and cannot control a cooling system.

Temperature Dial

Low Battery indicator

Statement of use: The 6005 can be used with most 24 volt gas, oil or electric heating and air conditioning systems, or gas millivolt heating systems. It cannot be used with 120 volt heating systems or heat pumps.

Operation

Turn the Temperature dial to select the desired temperature.

 Higher temperature counter clockwise (red)

 Lower temperature clockwise (blue)

NOTE: LED blinks when

batteries are low.

Caution: Heating system \ will stop when batteries die.



